


Control Panel Settings



Select mode:



= heating



= cooling



= automatic

(automatic switch between cooling and heating)

Temperature setting:

-3 0 +3

cooler - warmer

Adjustment of fan speed:



- low



- medium



- high



- automatic